

Heatwave 15™ Instructions

Safety & Comfort Notes:

1. This heater is intended for use **prior** to class, to attain a room temperature in the 92-97 degree “healthy hot yoga™” range, before class begins.
2. Do not operate this heater without operating humidifiers.
3. If operation during class is needed:
 - monitor studio temperature closely during operation
 - monitor humidity level is at minimum 20%
4. Avoid touching the front grill of this heater (and all heaters) with bare hands.
5. If you cannot reach the control knob easily and safely, please use a step ladder.

Starting:

Rotate the temperature knob on the upper side of the unit through the fan range and to the full hot upper limit in one smooth motion. If you wish to continue running it during class, rotate it slightly back from the full “max heat” position.

Shut Down:

The heater **MUST** be operated on ***Fan Only*** for a minimum of **3 minutes** before turning off completely.

No Heat?:

Fan Only for **3 minutes**, ***Off*** for **3-5 minutes**, then start smoothly, rotating the thermostat knob to the full hot upper limit.